

Assembly instructions

- 1. Lay the ladder flat on the ground with the "Wall Side" down.
- 2. Lift the end of the ladder up and position the Corner Stabilizer in desired mounting position (under to top rung) The ladder should rest in place over the stabilizer bar.
- 3. Place u-bolts (1) over the side of the ladder near the ladder rung, and over the Corner Stabilizer (2) in a 45 degree angle. NOTE: Position the u-bolts so that they straddle the ladder side rail and top ladder rung as shown above right.
- 4. Fasten the stabilizer (2) to the inside of the ladder using two mounting brackets (3) and four wing nuts (4).
- 5. Hand tighten wing nuts (4).
- 6. Flip the ladder/stabilizer over and press the rubber end caps on the ends of the stabilizer tube. Tap the caps on with a rubber mallet if needed to assure a tight fit.

Instruction #08127



TIE DOWN ENGINEERING • 255 Villanova Drive SW • Atlanta, GA 30336 www.tiedown.com (404) 344-0000 Fax (404) 349-0401