



*best in the*  
**LongRun**

# U-Bolt Spare Tire Carrier

## Installation Instructions

### Part #86091/86092



#### Part 86091 - Kit contains the following components:

#	Qty.	Part #	Description
1	1	17099-1	U-bolt Tire Carrier
2	2	10860	Hex Nut 7/16"-20

#### Part 86092 - Kit contains the following components:

#	Qty.	Part #	Description
1	1	17099-1	U-bolt Tire Carrier
2	2	10860	Hex Nut 7/16"-20
3	2	17099-2	Security Bracket

**U-bolt tire carrier is designed to mount a spare tire on top of your trailer tongue.**

- Carrier mounts most tire/wheels up to a 15" rim with a 4, 5 or 6 hole stud pattern.
- Carrier is designed to have the weight of the wheel on top of the tongue or frame of the trailer. It is not designed for any side or under mounting applications on the tongue or frame.
- Find a suitable location where the tire will lay flat on the tongue and not interfere with the loading of the boat or with any part of the coupler or brake actuator.
- Best location is closest to the bow of the boat so as not to increase tongue weight.
- Set the tire on top of the tongue. Install the U-bolt tire carrier from the bottom of the trailer so that the U-bolt wraps around the tongue and comes up through the wheel.
- The tire should be rotated so that the U-bolt passes through two holes of the wheel where the lug nuts would go.
- Thread one hex nut on each side of the u-bolt.
- Tighten each nut so that the tire does not move and is snug on the tongue.

#### **Spare Tire Carrier Kit with Security Brackets (kit #86092)**

- Thread one attachment bracket on each side of the u-bolt, thread side down.
- Tighten each bracket so it is snug on the installed hex nut.
- Position the brackets so that the oval holes on top are next to each other. A padlock can then be placed in the oval hole of the brackets to aid in prevention any theft.

